



REPLACEMENT PARTS

MODEL NO.
72215

CAPACITY
30/15 TON

DESCRIPTION
AIR / HYDRAULIC TELESCOPIC FLOOR JACK





DESCRIPTION
AIR / HYDRAULIC TELESCOPIC FLOOR JACK

CAPACITY
30/15 TON

MODEL NO.
72215

REPLACEMENT PARTS

INDEX NO.	DESCRIPTION	PART NO.	REQ'D NO.	INDEX NO.	DESCRIPTION	PART NO.	REQ'D NO.
1	Checkball	222436	1	66	Bushing	222609	1
2	Spring	222542	1	67	Ring Nut	222611	1
3	Checkball	222376	1	68	Spring	222612	1
4	Spring	222543	1	69	Spring	222613	1
5	Washer	222544	1	70	Spring Guide	222614	1
6	Plug	222546	1	71	Shaft	222616	1
*7	Packing	222547	2	*72	Packing	222617	1
8	Hydraulic Base	222548	1	*73	Packing	222618	1
9	Ring	222549	1	74	Valve	222619	1
10	Pipe Fitting	222551	1	75	Silencer	222621	1
11	Pipe Fitting	222552	1	76	Cover	222622	1
12	Pipe Fitting	222553	1	77	Screw	222623	3
13	Reservoir	222554	1	78	Air Pump	222624	1
*14	Packing	222556	1	79	Pipe	222626	1
15	Ring Nut	222557	1	80	Valve	222627	1
16	Screw	222558	4	81	Overload Valve & Fitting	222628	1
17	Saddle Base	222559	1	82	Pipe	222629	1
18	Secondary Ram	222561	1	83	Silencer	222631	1
19	Dust Seal	222562	1	84	Screw	222632	2
*20	Packing	222563	1	85	Main Chassis Assembly	222635	1
*21	Primary Ram	222564	1	86	Screw	222633	2
*22	Dust Seal	222566	1	87	Handle	222634	1
23	Cylinder	222567	1	88	Screw	222636	1
*24	Packing	222568	1	89	Washer	222637	2
*25	Packing	222569	1	90	Retaining Ring	222638	2
26	Pipe	222571	1	91	Wheel	222639	2
27	Plug	222572	1	92	Wheel Bushing	222641	2
28	Washer	222573	1	93	Nut	222642	2
29	Pump Assembly	222574	1	94	Screw	222643	2
30	Filter	222575	1	95	Protection Cover	222644	1
31	3-15/16" Extension	222580	1	96	Pipe	222646	1
32	2" Extension	222585	1	97	Pipe	222647	1
33	Retaining Ring	222576	1	98	Pipe	222648	1
34	Pipe Fitting	222411	1	99	Screw	222508	2
35	Pipe Fitting	222577	1	100	Control Valve	222510	1
36	Cover	222578	1	101	Pipe Fitting	222509	1
*37	Packing	222579	1	102	Packing	222518	1
38	Cylinder	222581	1	103	Rod Stop	222511	1
*39	Packing	222582	1	104	Handle Grip	222519	2
40	Aluminum Piston	222583	1	105	Control Support	222521	1
41	Spring	222584	1	106	Lever	222512	1
*42	Packing	222412	1	107	Rod	222649	1
43	Valve Casing	222586	1	108	Pipe	222522	1
*44	Packing	222417	1	109	Screw	222524	2
45	Spring	222587	1	110	Quick Release Pipe Fitting	222526	1
46	Washer	222447	2	111	Filter Reducing Adapter	222527	1
47	Pipe Fitting	222588	1	112	Filter	222528	1
48	Stop Pin	222589	1	113	Air Inlet	222523	1
49	Spring	222591	1	114	Pipe Fitting	222468	1
50	Checkball	222372	1	115	Screw	222529	2
51	"T" Pipe Fitting	222592	1	116	Washer	222531	2
52	Pipe Fitting	222593	1	117	Lower Handle Tube Assy.	222650	1
*53	Packing	222594	2	118	Spring	222514	1
54	Valve	222596	1	119	Split Pin	222516	1
55	Washer	222597	1	120	Sheath	222517	1
56	Pipe Fitting	222598	1	121	Screw	222532	2
57	Air Pump Cylinder	222599	1	122	Washer	222651	4
*58	Packing	222601	2	123	Bushing	222534	2
*59	Packing	222602	2	124	Washer	222533	4
60	Aluminum Piston	222603	1	125	Nut	222537	2
61	Screw	222458	4	126	Stop Pin	222538	1
62	Hydraulic Pump Housing	222604	1	*127	Complete Exhaust Valve Assy.	222655	1
63	Flange	222606	1				
*64	Packing	222607	1				
*65	Packing	222608	1		Repair Kit for Model 72215	222345	1

* Designates parts included in the repair kit